

Maintain the 3400 and 5400N


This section provides maintenance information for the 3400 and 5400N systems, including the integrated Everest 400 printer.

 **Important!** For optimum performance, keep the 3400 and 5400N in a clean, dust-free environment.

Overview

Regular preventative maintenance of your system can help to ensure error-free recordings and clean printed labels. Maintenance also involves cleaning the system.

Cautionary Information

 **Caution:** To avoid damaging the 3400 or 5400N during maintenance:

- Never use oils, silicone, or other lubricants on any part of the system.
- Use only non-abrasive cleaners to wipe down the surfaces of your autoloader.
- Never use cleaners to clean the embedded PC.
- Avoid pouring cleaners directly onto the autoloader. Instead, apply the cleaner a clean, lint-free cloth.
- Observe precautions for electrostatic-sensitive devices whenever you access the embedded PC.

Preventative Maintenance

You must perform routine maintenance to keep the system operating at optimum performance. The [Preventative Maintenance Schedule](#) on page 2 lists maintenance tasks, task frequency, and references to cleaning instructions in this document.

 **Important!** Failure to follow the maintenance schedule may void your warranty.

 **Note:** Your system may require more frequent maintenance if used in a dusty area, such as a store or warehouse.

Before you begin:

1. Power off the **autoloader**.
2. If you have a 5400N, power off the **embedded PC**.
3. Disconnect the **power cord**.
4. Follow the [Preventative Maintenance Schedule](#) on page 2.

Preventative Maintenance Schedule

Task	Tools	Frequency
Autoloader Maintenance		
Wipe down the lift arm shaft and pay close attention to: <ul style="list-style-type: none"> The area around the base of the shaft The area just above the lift arm 	Lint-free cloth	Weekly
Wipe down all surfaces of the autoloader, including: <ul style="list-style-type: none"> Sides and top Door Output bin Carousel Top surface on the lift arm 	<ul style="list-style-type: none"> Lint-free cloth Non-abrasive, all-purpose cleaner 	Weekly
Remove dust and debris from the fan at the back of the autoloader.	Can of compressed air	Monthly
Remove dust and debris from the openings at the back of the autoloader.	Vacuum	Monthly
Remove dust and debris from the front and inside of the autoloader.	Can of compressed air	Monthly
Integrated Everest 400 Printer Maintenance		
Clean the print head. Refer to the Clean the Print Head section on page 3.	<ul style="list-style-type: none"> Sponge swabs with long handles (included in the Everest cleaning kit) 99% Isopropyl alcohol 	After 2000 discs (as needed) or at every ribbon change
Clean the tacky rollers. Refer to the Clean the Tacky Rollers section on page 4.	<ul style="list-style-type: none"> Sponge swabs with long handles (included in the Everest cleaning kit) 99% Isopropyl alcohol 	After 2000 discs or at every ribbon change

Clean the Everest 400 Printer

Regular cleaning helps to keep your Everest 400 printer in optimal operating condition.

Clean the Print Head


Tools required:

- Sponge swabs with long handles (included in the Everest cleaning kit)
- 99% Isopropyl alcohol

1. Access the **print head**.

- Lift the **printer cover latch** to open the cover.
- Lower the **printer cover**.
- Turn the **center latch** counterclockwise to unlock it.
- Remove the **print ribbon carrier**.

Important! The ribbon carriers cannot be removed from the printer unless the system is powered on.



2. Clean the **print head**.


Caution! Do not scratch the print head. Remember the following tips:

- Always wipe from one end of the print head to the other without stopping in the middle.
- Only wipe the area indicated.

- Apply **isopropyl alcohol** to the **sponge swab**.
- Use the **sponge swab** to wipe across the **print head** from one end to the other in the direction shown below.

Note: Do not remove the print head component from the inside of the printer. The component is shown outside of the printer for instructional purposes only.

- Repeat as needed until the **print head** is clean of dust and debris.
- Use the **sponge swab** to remove any waxy buildup from the **roller** below the print head.




3. Prepare the **printer** for use.
 - a. Install the **print ribbon carrier**.
 - b. Turn the **center latch** clockwise to lock it.
 - c. Close the **printer cover**. The system is ready for use.

Clean the Tacky Rollers

Tools required:


- Sponge swabs with long handles (included in the Everest cleaning kit)
- 99% Isopropyl alcohol

1. Remove the print ribbon carrier.
 - a. Lift the **printer cover latch** to open the cover.
 - b. Lower the **printer cover**.
 - c. Turn the **center latch** counterclockwise to unlock it.
 - d. Remove the **print ribbon carrier**.
- ⓘ **Important!** The ribbon carriers cannot be removed from the printer unless the system is powered on.
2. Remove the **print ribbon**. For specific instructions, refer to the *Change the Print Ribbon* procedure in the User Guide.



Print Ribbon Carrier Center Latch

3. Clean **tacky roller 1** on the print ribbon carrier.
 - a. Apply **isopropyl alcohol** to the **sponge swab**.
 - b. Use the **sponge swab** to clean **tacky roller 1**.
 - c. Use the **sponge swab** to remove any waxy buildup from other parts of the **print ribbon carrier**.



4. Inside the printer, use the sponge swab to wipe **tacky roller 2**.
5. Prepare the **printer** for use.
 - a. Install the **print ribbon** on the print ribbon carrier.
For specific instructions, refer to the *Change the Print Ribbon* procedure in the User Guide.
 - b. Install the **print ribbon carrier** in the printer.
 - c. Turn the **center latch** clockwise to lock it.
 - d. Close the **printer cover**.

The system is ready for use.

